Guidelines for Input Terminals Version 1.01

Contents

- 1) Input Terminal Assignment
- 2) Response of Detachable Input Terminal

1) Input Terminal Assignment

Applicable commands

4.3 Input switch instruction?

4.4 Input switch query INPT?

4.9 Input toggling query INST?

Use the following information when assigning input terminals of a projector.

RGB 11 to 19 (For analog RGB signals)

D-SUB terminal / BNC terminal x 5 / DVI-I terminal (ANALOG) / SCART terminal M1-DA terminal (ANALOG)

VIDEO 21 to 29 (For composite video and component video signals)

RCA terminal / RCA terminal x 3 / BNC terminal / BNC terminal x 3 / S terminal D terminal / SCART terminal

DIGITAL 31 to 39 (For digital signals)

DVI-I terminal (DIGITAL) / DVI-D terminal / HDMI terminal / SDI terminal / iLINK terminal M1-DA terminal (DIGITAL) / M1-D terminal / DisplayPort / Wireless HDMI

STORAGE 41 to 49 (For storage media)

USB (Type A) / PC Card Type II / Compact Flash / SD Card

NETWORK 51 to 59 (For Image transmission)

Wired LAN Connection

RJ-45 terminal / USB (Type A) / PC Card Type II / Compact Flash / SD Card

Wireless LAN Connection

Built-in Wireless LAN / USB (Type A) / PC Card Type II / Compact Flash / SD Card USB Connection

USB (Type B) / Wireless USB

Bluetooth Connection

Bluetooth

Supplement:

Make RGB/VIDEO combination terminals RGB terminals Make RGB/DIGITAL combination terminals RGB terminals

JAPAN BUSINESS MACHINE AND INFORMATION SYSTEM INDUSTRIES ASSOCIATION

2) Response of Detachable Input Terminal

Match responses of detachable input terminal devices, such as option board, USB memory and PC card, among the input terminals of the projector to the selection specification of projector input terminals.

Example: If a projector with a STORAGE terminal does not mount a STORAGE device.

Projector that enables selection of an input terminal to a STORAGE terminal INPT 41 (STORAGE command) \rightarrow OK INST ? \rightarrow Respond by including a STORAGE terminal

Projector that disables selection of an input terminal to a STORAGE terminal INPT 41 (STORAGE command) \rightarrow ERR2 INST ? \rightarrow Respond without including a STORAGE terminal

Example: If a projector with STORAGE/NETWORK combination terminals mounts a NETWORK device.

Projector that enables selection of an input terminal to a STORAGE terminal INPT 41 (STORAGE command) \rightarrow OK INPT 51 (NETWORK command) \rightarrow OK INST ? \rightarrow Respond by including STORAGE and NETWORK terminals

Projector that disables selection of an input terminal to a STORAGE terminal

INPT 41 (STORAGE command) \rightarrow ERR2

INPT 51 (NETWORK command) \rightarrow OK

INST ? → Respond by including a NETWORK terminal. (A STORAGE terminal is not included)